Verigo Setup

5 September 2018

Document Content

Setup Steps:

- 1. Download Verigo Application from Play Store
- 2. Install and Open Verigo Application
- 3. Login with Company Account
- 4. Configure Verigo Pod Settings
- 5. Pair Verigo Pod
- 6. Activate Verigo Pod
- 7. View Verigo Pod Data
- 8. Multiple Verigo Pods per User
- 9. Uninstall Verigo Pod

1. Download Verigo Application from Play Store







۰ 🔌 🙈 🖗	₩ *	🚡 📶 2% 🖪	07:50
← ver	igo		Ļ
Did you me	ean: vertigo		
	Verigo Verigo Corp		
	12 MB * 3,6 *		
Ve.	Verigo - Simple & Sma PayMango India Privateo	art Digital A	:
	20 MB • 5,0 *		
	Vertigo Racing Deep Byte Studios SRL		:
	77 MB • 4,6 *		
	LoggerLink Campbell Scientific, Inc.		:
0	13 MB • 4,8 *		
	Vertigo BookIt		:
V	16 MB • 4,1 *		

2. Install and Open Verigo Application



Mobile app and user interface designed for Verigo wireless data loggers.

READ MORE







Performance may vary on older devices.



Mobile app and user interface designed for Verigo wireless data loggers.

Small improvement to log decompression

3. Login with Company Account



🔊 ≵ 🖗 ୷ 6% 💈 08:03 What would you like to do? Configure + Activate Now **Preconfigure Settings** for future use **Activate Nearby Device** with preconfigured settings Ø Ö Nearby Cloud Settings

Note: For every client we will have 1 company account.

NHLS account to be confirmed.

Note: For every client we will have a Verigo Pod Configuration Sheet.

NHLS: Verigo Pod Configuration Sheet 4. Configure Verigo Pod Settings

NHLS Logging Interval: 5 minutes

▶ 🕫 🏊	ः 🕫 🕸 🗟 ୷ ६% 🗷 08:03	▶ 🕫 🐟	ः ३ 🗟 .त∣ 6% 🗵 08:03	± ∞	ॼ ≱ क्वि। 6% ॿ 08:05	.± 🕫 🐥	80 ۷ 8% الله. 🧟 🛪 📾
		< ● —	Start - ○ ○ →	← Start	— 0 →	← s	
What would you like to do?	SESSION NAME		SESSION NAME		SESSION NAME		
		💉 Session Name 🕯	Required	💉 Session Name 🌒	Required	🔗 Session Name 🌒	Requir
		LOGGING DETAILS		LOGGING DETAILS		LOGGING DETAILS	
Configure + Activate Now	Logging Interval	15 Minutes	Logging Interval	5 Minutes	Logging Interval	15 Minu	
		 Estimated Durat 	ion 🌗 416 Days	C Enter Pod Name:	ays	Estimated Duratio	n 🖪 416 Da
Preconfigure Settings for future use Activate Nearby Device with preconfigured settings	Logging Delay	No Delay		lay	#)e	
	ALERT SETTINGS		Custom Name		5 💌 Minutes 💌		
	or future use	Alert After 🌗	0 Minutes	Scan Barcode	tes	$\mathbf{\Xi}$	iut
		Low Temp Alarn	n Limit − °C		CANCEL - °C	CLEAR	DONE
		High Temp Alarr	n Limit °C		- °C	High Temp Alarm	Limit -
	Nearby Device	Low RH Alarm L	imit %RH	Low RH Alarm Limit	%RH	Low RH Alarm Lin	nit %
	configured settings	High RH Alarm L	imit %RH	High RH Alarm Limit	%RH	High RH Alarm Lin	nit – %
		ADVANCED SETTINGS		ADVANCED SETTINGS		ADVANCED SETTINGS	
		🛲 Ouality Analysis 🚺		Guality Analysis		Guality Analysis	0
Start Stop	Nearby Cloud Settings	Start Stop	Nearby Cloud Settings	Start Stop Nearby	Cloud Settings	Start Stop Ne	🔊 🔺 💭

5. Pair Verigo Pod









6. Activate Verigo Pod







7. View Verigo Pod Data





8. Multiple Verigo Pods per User



- Each driver will have two cooler boxes with two pods.
- Both pods must therefore be activated.
- Please repeat the setup procedure for multiple pods.

9. Uninstall Verigo Pod



Graph

Settings

Status



■ 9 ま 3 . 1 10% **■** 08:16



